

Maintenance and Repair
Embelton Australian Longboards



Maintenance

Your laminate floor is designed with low maintenance in mind. Follow these simple steps to achieve many years of enjoyment from your floor:

- Sweep or vacuum as often as necessary to remove any loose dirt or grit before it can scratch the floor.
- When a spill occurs, soak up the bulk liquid promptly.
- In areas of excessive traffic and wear, please make use of runners or area rugs.
- Use felt protectors under heavy pieces of furniture and chairs. Do not use rubber as it may leach into the floor.
- Use protective mats at all exterior entrances. Do not use rubber-based furniture or mats as the rubber may leach into the floor.
- Spiked heels or shoes in need of repair can severely damage your floor.
- Damp mop only – avoid excessive amounts of water. Steam mops must not be used.
- Never use oil soaps, wax, liquid or other household products to clean your floor.
- Keep animal nails trimmed.
- Protect your floor when using a dolly for moving furniture or appliances.
- Never slide or roll heavy furniture or appliances across the floor.
- Maintain relative humidity levels between 30% and 70%.

Repair

If part of your laminate floor gets damaged, it can easily be replaced. Flooring can be unclicked and re-laid with new boards of the same colour and style.

Lightly applied nail polish remover will remove most stains.

Technical specifications:

- Colours: Spotted Gum, Ironbark Coastal Blackbutt, Stringybark, Blue Gum, Lemon Scented Gum
- Unilin click system
- Board dimensions:
1800 x 168 x 12 mm
- 8 boards per pack to cover
2.419 sq.m