

Maintenance and Restoration
Embelton Bamboo Flooring



Bamboo Coffee

Maintenance

Your bamboo floor is designed with low maintenance in mind. Follow these simple steps to achieve many years of enjoyment from your floor:

- Sweep or vacuum as often as necessary to remove any loose dirt or grit before it can scratch the floor.
- When a spill occurs, soak up the bulk liquid promptly.
- In areas of excessive traffic and wear, please make use of runners or area rugs.
- Use felt protectors under heavy pieces of furniture and chairs. Do not use rubber as it may leach into the bamboo.
- Use protective mats at all exterior entrances. Do not use rubber-based furniture or mats as the rubber may leach into the bamboo.
- Spiked heels or shoes in need of repair can severely damage your floor.
- Damp mop only – avoid excessive amounts of water. Steam mops must not be used.
- Never use oil soaps, wax, liquid or other household products to clean your floor.
- Keep animal nails trimmed.
- Protect your floor when using a dolly for moving furniture or appliances.
- Never slide or roll heavy furniture or appliances across the floor.
- Maintain relative humidity levels between 30% and 70%.
- If your floor becomes scratched or dull, repairs can often be made using repair accessories.
- Proper care and maintenance can extend the life of your floor for many years. Over time, a recoating may be desirable.

Restoration

Your bamboo floor can be restored several times by sanding back the veneer and then applying a polyurethane or water-based coating. Sanding and re-coating should only be carried out by a professional flooring contractor.

Please contact Embelton Flooring prior to any rectification.

Technical specifications:

- Compressed, hot pressed strand woven bamboo
- Colours: Natural, Coffee, Sepia Daintree, Nullarbor, Tiger
- 4-Sided Unilin click system
- Board dimensions:
1840 x 122 x 14mm
- Factory coated with 10 layers of German Klumpp UV cured acrylic
- Janka hardness rating: 15